

Setting instructions SWG1



**IFM CR1074 LED display programmed as
Forklift truck with 3 load storage units**

Edition: V1.0 (08.2022)

Table of contents

Hints	3
General remark	3
Product identifications	3
Document identifier	3
Production	3
Introduction	4
About this manual	4
Disclaimer	4
Copyright notices	4
Use for the intended purpose	4
Qualifications of the operating personnel	4
Safety information	5
Warning information and symbols	5
Purpose of use	6
General information	6
Warnings	7
Installation	7
Load balancing	8th
The function keys	8th
System Settings & Password	8th
Calibration	9
Setting date & time	10
Start setup mode	10
Setting the time zone	10
Setting date and time	11
Notes	12

Hints

General remark

This document is part of the system provided by KST Engineering GmbH.
The documentation includes information for the CR1074 control console

Product identifications

Product type:	IFM CR1074 console
Software product name:	KST Engineering GmbH SWG-1 display
Firmware system:	Codesys 3.5.16.5 Package FW21015

Document identifier

Author: KST / A.Emmerich

Published: September 5, 2022

Edition: 1.0

Description of the edition: V1.0 / August
2022 AE / First version / German

production

KST Engineering GmbH

At Dwarstief 15

26826 Weener

Germany

Tel.: +49 (0) 4953 990725

introduction

About this manual

This document is a component of the devices provided by KST Engineering GmbH. systems. Keep this manual in a safe place and ensure that it is freely accessible to all users.

Disclaimer

The contents of this manual are subject to change. KST Engineering GmbH provides no warranties for this material, including any warranties of merchantability or fitness for a particular purpose. KST Engineering GmbH assumes no liability for errors contained in this manual or for direct or indirect damages in connection with the provision or use of these materials.

Copyright notices This manual is protected by copyright. All rights reserved. The manual may not be copied, reproduced or translated into another language without the prior written consent of KST Engineering GmbH.

Use for the intended purpose

This device/system may only be used for the purpose specified in this manual. Any other use will be considered inappropriate. The manufacturer assumes no liability for damage caused by inappropriate or unauthorized use.

This device/system may only be used in a technically perfect condition.

Qualifications of operating personnel This device/system may only be operated by appropriately qualified personnel, ie persons who:

1. are familiar with the operation or installation and commissioning
2. know the applicable legal regulations to prevent accidents
3. have read and understood the documentation or have received appropriate training or instruction have received.

Safety information

Warning information and symbols

Information of particular importance is marked within the user manual using the following names and symbols:



This symbol refers to hazards associated with the activity described that could result in injury.



This symbol indicates hazards that could cause property damage, e.g. B. Damage to the equipment or the environment.



The hand icon points to sections where you can find more information or tips.



This symbol informs you that the warranty may be void. Make sure you have read all safety instructions in this document and follow them when operating the system.

Make sure you have read all safety information in this documentation and observe it when using the system.

Always keep these instructions in a safe place. Provide a copy of the instructions to each operator.

The control system may only be operated with your hands. Never use sharp objects to press the buttons.

If the device is damaged, the system may no longer be used.
Disconnect it from the power supply. The limiter must be protected from steam, liquid and dust, especially if the display window is damaged.

Only clean the device with mild cleaning agents. Never use cleaning agents containing solvents or aggressive or abrasive agents.



When disposing of the limiter, the electronic components must be disposed of as hazardous waste in accordance with local regulations.

Purpose of use



This system was developed in accordance with recognized safety standards. However, improper use of the device can result in injury or death to the operator and others, as well as damage to equipment and other property.

The system may only be used for its intended purpose and must be in perfect technical condition. There should be no doubt that this system contains both electronic and mechanical components and therefore the risk of errors cannot be completely ruled out.

Errors that lead to a possible security risk must be corrected immediately.

This system is designed exclusively for the tasks described in this documentation. It may not be used for any other purposes.

Caution: This system is not intended to replace the operator's lack of practical experience or common sense in the use of the equipment. Responsibility for the entire operating process and all resulting consequences lies solely with the operator.

The manufacturer assumes no liability for any damage or injury resulting from inappropriate or unauthorized use of the system. The risk lies solely with the user.

General information

The SWG-1 system must be calibrated upon completion of system installation, after machine changes, or any time an inaccuracy is detected. During calibration, the sensors installed in the machine are tuned.

Before starting calibration, you should read the procedure completely. The purpose of this manual is to provide necessary calibration information prior to operating the system. For a description of the system and console controls, see the Operator's Manual.

Warnings

Always follow the crane manufacturer's operating instructions and load tables for specific information on operating the crane and load limits.

However, the SWG-1 is not, and should not be construed as, a substitute for operator common sense, experience, and application of proper operating procedures.

The operator is responsible for operating the truck in accordance with the manufacturer's specified parameters.

The machine operator must ensure that all warnings and instructions provided by the manufacturer are fully understood, observed and retained with the machine.

Before operating the truck, the operator must carefully read and understand the information contained in the Operator's Manual to ensure they are familiar with the operation and limitations of the SWG-1.



BEFORE STARTING THE MACHINE, THE SYSTEM MUST BE CALIBRATED. ALL STEPS MUST BE PERFORMED AND COMPLETED. TO AVOID MATERIAL DAMAGE AND SERIOUS OR EVEN FATAL ACCIDENTS, PROPER ADJUSTMENT OF THE SYSTEM MUST BE ENSURE BEFORE OPERATION OF THE MACHINE.

MAKE SURE ALL SETTINGS/DATA HAVE BEEN ENTERED CORRECTLY!

Commissioning



Before using the device, ensure that you have read all relevant instructions provided by the device manufacturer regarding the updating and use of the device.



This manual and the device manufacturer's manuals must be read carefully and fully understood before starting work.



All entries must be made in accordance with the actual conditions of the device. If incorrect entries are made, the device cannot function properly and will not provide the necessary information in dangerous situations

necessary protection for the operator or equipment.

Before making any changes to the system, always check the sensor and power cable.

The system may only be adjusted by KST Engineering GmbH customer service or an authorized KST representative. Incorrect adjustment may result in inaccurate data or device malfunction. In this case all guarantees expire.


Load balancing

The function keys

The display is controlled with the function keys F1-F6. The exact functions of the function keys are explained in the [Display](#) chapter. The rocker switch is used in the submenus and settings.

Function keys:

Cross rocker:



System Settings & Password

To get to the system settings, you must press the button in the operating display to get to the main menu.



Once you have reached the main menu, you will find the "System Settings" menu item at the bottom. Use the rocker switch to navigate there and confirm your selection. Now the system will ask for the password. To access the settings, enter the following password:

Password: 45259

After entering the service menu opens.



In order for the load display to show the correct load, the sensor must be calibrated. First with the minimum load value then with the maximum load value. The menu items load threshold and measurement time can be set independently of the load calibration.

calibration

1. Use the rocker switch to click on the "Load Calibration Min" button.
2. Make sure that the fork is free of load



Current comparison data:

The current comparison data is displayed here
Shown

Current values:

The current digits are displayed here and the
current load from the existing calibration
value.

3. Press "SET" and enter the current load (fork load free = 0t)
4. Press OK. Now the system adopts the current digits to those previously entered load value.
5. Now press "EXIT" to return to the system menu
6. Use the rocker switch to go to the "Load Calibration Max" button



Current comparison data:

The current comparison data is displayed here
Shown

Current values:

The current digits are displayed here and the
current load from the existing calibration
value.

7. Press "SET" and enter the current load (fork + test weight = 10t)
8. Press OK. Now the system adopts the current digits to those previously entered load value.
9. Load balancing is finished. Exit takes you back to the system menu
10. Now set the load threshold. This value indicates the threshold at how many tons the measurement should start. (standard value 300 kg)
11. The measuring time determines the length of the measuring process

Set date & time


Start setup mode



MAKE ONLY THE SYSTEM SETUP CHANGES DESCRIBED HERE. ADJUSTING THE DISPLAY CAN RESULT IN SYSTEM FAILURE.

Disconnect the device from the circuit. u Carry out the following actions at the same time:

Press and hold any 2 buttons on the device at the same time. Turn on a device. Device restarts. Select the "Launch Setup" button in the menu and confirm. Device is in setup mode.



Set time zone

To set the date and time (system time):

Navigation path: [Launch Setup] > [System Setup] > [Date and Time] > [Time Zone] tab

Menu page shows the following information

[Time Zone Category] Preselection of the time zone region. Selecting a region acts as a filter on the

List e.g. All, America, Asia, Australia, Europe, US

[Time Zone] time zone e.g. US/Michigan, Europe/London, Europe/Berlin

Setting date and time

To set the date and time (system time):

Navigation path: [Launch Setup] > [System Setup] > [Date and Time] > [System Time] tab

Menu page shows the following information:

[Year]	Year 2000...2100
[month]	Month 1 ... 12
[Day]	Day 1...31
[Hour]	Hour 0...23
[min]	Minutes 0...59
[sec]	Second 0...59
[Time Zone]	Time zone list

Select the desired number field. Marked number field has black frame. u Use [y] / [y] to set the desired value.

When you leave the page, the changes are saved.

[illegible]



A series of horizontal lines for writing, consisting of 28 lines.