





Sensor cable colours standard:
brown=+Vb
black=4..20mA
blue=GND
Otherwise please view
Configuration Sheet





Sensor4




Master Blatt 2




Master Blatt 2



Sensor3



Master Blatt 2



Master Blatt 2

Winden-Rückmeldung Winde1; High=Winde läuft, LOW=Winde steht

Winch-Feedback Winch1; High=Winch running, LOW=Winch standing

Winden-Rückmeldung Winde2; High=Winde läuft, LOW=Winde steht

Winch-Feedback Winch2; High=Winch running, LOW=Winch standing

Error-Reset (optional)

B-IN7

B-IN6


Master Blatt 2

C-IN11


C-VBBS


C-GND

Master Blatt 2



Änderungen			Datum	Name	Bezeichnung:	Blattzahl: 4
Datum	Name	gez.:	4.02.19	J.Kerkow	GHC-1nr Ausführung Master 401 Eingänge / Inputs	
		gepr.:				Blatt-Nr.: 1
					Zeichnungs-Nr.:	
					263122-01	





Änderungen			Datum	Name	Bezeichnung:	Blattzahl: 4
Datum	Name	gez.:	4.02.19	J.Kerkow	GHC-1nr Ausführung Master 401 Ausgänge 1 / Outputs 1	
		gepr.:				Blatt-Nr.: 3
					Zeichnungs-Nr.:	
					263122-01	

